

Installation Height Measurements

In addition to the width and drop measurements, the installation height is required so that the any cords comply with the Blinds Safety Regulations.

Recess Fitting Blinds



Measure from the full drop where you are going to fit the blind to the floor.
= Installation Height



Tip If you find it too difficult to measure the full drop, you can measure where you plan to fit the head rail down to the window sill. **1**

Then from the top of the window sill down to the floor. **2**

Add the two figures together and you will have in installation height for the recess. **3**

Installation Height Exact /Outside Fitting



Measure where you plan to fit the top of the blind down to the floor.

= Installation Height