

# **Resetting Limits Blocout XL Blinds With Motor**

**Take off battery cover to view the P2 buttons and use the left one**

## **To Cancel Pre-set Limits:**

P2 - DOWN - P2

\* Motor will jog on each press of P2

## **To Set New Limits:**

Start with blind not too close to top or bottom

P2 - UP - P2

\* Motor will jog on each press of P2

Press Up to move blind towards top

When near top, press P2 while blind is moving, it will start to 'step', making it easier to stop in exactly the right place

Hit Stop when there is about 25mm of fabric visible at top, take care not to go too far or you may damage the blind

HOLD Stop for 4-5s to set top limit, blind will jog to confirm

Press Down to move blind towards bottom

When near bottom, press P2 while blind is moving, it will start to 'step', making it easier to stop in exactly the right place.

Hit Stop when blind has just closed against bottom edge of window opening, take care not to go too far or you may damage the blind

HOLD Stop for 4-5s to set bottom limit, blind will jog to confirm

Limits are now set.